

### L300 Erişim Cihazlarında WAN - Uzak bağlantı için yapılması gerekenler:

- Bağlanılacak uzak bilgisayarın tüm Windows updateleri yapılmış olmalıdır. (Özel updateler dahil)
- Uzak bilgisayarda güncel vSpace yazılımının yüklü ve register yapılmış olması gerekmektedir.
- Uzak makine üzerinde 3389 ve 27605 Portlarının TCP & UDP olarak açılması gerekmektedir.
- L300 erişim cihazları otomatik IP alacak şekilde yapılandırılmalıdır.
- L300 erişim cihazları açıldıktan sonra ilk connection ekranında "Enter a vSpace Hostname or IP address" kısmına bağlanacağınız makinenin Dış İp'sini yazıp connecte bastığınızda Uzaktaki ana makinenize bağlantı sağlamış olursunuz. (Uzaktaki ana makinenin Gerçek IP adresinin statik olması gerekmektedir. Eğer statik IP adresiniz yok ise [www.whatismyip.com](http://www.whatismyip.com) sitesinden gerçek IP'nizi görebilirsiniz).



The screenshot displays the NComputing vSpace connection interface. At the top left is the NComputing logo, and at the top right is the vSpace virtualization software logo with a device image. Below the logos, there are two radio buttons: "Select a vSpace connection" (which is selected) and "Enter a vSpace hostname or IP address" (which is circled in red). Under the selected radio button is a list box labeled "Available connections". To the right of the list box are four buttons: "Connect", "Refresh", "Device setup", and "Device information".